

Resistance to chemicals is tested over a 24 hour contact period at room temperature, followed by rinsing with cold water. Polyflor Ltd believe this simulates the worst situation where spillages are not removed immediately and are only cleaned by normal maintenance.

U – Unstained                      A - Slight stain                      B - Moderate stain                      C - Heavy stain                      E - Appearance as above plus slight surface disturbance

<i>Chemical</i>	<b>6622</b>	<b>6623</b>	<b>6624</b>	<b>6625</b>	<b>6422</b>	<b>9908</b>	<b>9909</b>	<b>9814</b>	<b>9815</b>	<b>9818</b>	<b>9929</b>	<b>9869</b>	<b>9816</b>	<b>9819</b>	<b>9841</b>	<b>9928</b>	<b>9840</b>	<b>9938</b>	<b>9841</b>
1 Acetic Acid Glacial	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
2 Acetic Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
3 Acetic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
4 Boric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
5 Citric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
6 Hydrochloric Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
7 Hydrochloric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
8 Hydrochloric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
9 Lactic Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
10 Nitric Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
11 Nitric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
12 Nitric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
13 Oxalic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
14 Perchloric Acid 60% Solution	AE	AE	U	A	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
15 Phosphoric Acid Concentrated	U	U	U	A	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
16 Phosphoric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
17 Pyrogalllic Acid	A	A	A	B	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
18 Sulphuric Acid Concentrated	AE	AE	UE	AE	AE	BE	AE	AE	UE	AE	AE	AE	AE	UE	UE	BE	AE	BE	UE
19 Sulphuric Acid 50% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
20 Sulphuric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
21 Tannic Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
22 Tartaric Acid 10% Solution	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
23 Thioglycollic Acid Concentrated	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
24 Absolute Alcohol	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U
25 Amidol 10% Solution	A	A	A	A	U	U	A	A	A	A	U	A	A	A	A	U	A	U	A





